


INSTALLATION PROCEDURES:

1. PADMOUNTED TRANSFORMERS SHALL BE LOCATED A MINIMUM 3m (10') FROM ANY COMBUSTIBLE SURFACES OR MATERIAL ON A BUILDING OR 6m FROM ANY DOOR OR WINDOW, ANY VENTILATION INLET OR OUTLET AS PER THE 'ELECTRICAL SAFETY CODE' SECTION 26-242
2. NO PLANTS, FIRE HYDRANTS, OR LUMINAIRE POSTS SHALL BE INSTALLED WITHIN 3m (10') OF THE FRONT OF THE TRANSFORMER
3. ALL WORK SHALL BE INSPECTED BY OTTAWA RIVER POWER CORPORATION PRIOR TO BACKFILLING.
4. BOLLARDS ARE REQUIRED IN TRAFFIC AREAS FOR PROTECTION OF THE TRANSFORMER. SEE DWG. SDUG008 FOR BOLLARD DETAIL. IF BOLLARDS ARE REQUIRED, EXTEND COMPACTED BASE 1000mm FROM THE WALL. IF BOLLARDS ARE NOT REQUIRED, EXTEND BASE 300mm FROM THE WALL.

		OTTAWA RIVER POWER CORPORATION	
		TRANSFORMER BASE (PAD & FOUNDATION) INSTALLATION	
DWN.	ALEX REAVIE	DWG NO.	SDUG001
APP.	DOUG FEE P. ENG.	SCALE	1:30
DATE	MAY 24, 2006	SHEET	0